





ORIGINAL OUTDOOR


Original Outdoor

 **Material**
100% Acrylic or 100% Olefin

 **Filling**
Expanded Polystyrene (EPS)


 **Litres**
360 Litre


 **Coating**
Water and dirt repellent


 **Weight product**
6.65 kg

 **Dimensions**
180 x 134 cm


 **Weight product + packaging**
9.5 kg

 **Dimensions packaging**
60 x 60 x 110 cm

 **Batch number**
In the bag, close to the zipper on a white label


 **Washing instructions**

- Wash cover at 30 °C
- Wash inside out
- Do not tumble dry
- Do not dry clean
- Please iron the cover on the lowest heat to activate the water repellent coating after washing

 **Features**

- The one and only Original for outdoor use
- Countless ways to sit, hang, laze and lounge
- UV-resistant
- Water-resistant
- Stain-resistant
- Bleach cleanable

- Water repellent fabric with excellent color fastness (100% solution dyed_)
- Machine washable cover

 **Recommendations**

- Intensive use may cause the filling to shrink
- With the refill you can completely fill your bag from scratch (350 litre) or refill your bag (100 litre)
- Iron your Original on a regular basis to maintain its water repellence
- Treat your Original outdoor like a regular garden cushion and store it indoors when it rains

HOW TO ENJOY YOUR PRODUCT TO THE MAX


Keeping it clean

- Use a wet cloth to gently cleanse the area by patting it
- Wash cover at 30 °C
- Wash inside out





Original Outdoor



Super strong high quality fabric

